



1. Remove protective cap from the Safety Lancet.



3. Place the lancet against the puncture site.



4. Push the release button.



5. Dispose lancet after use.
Do not use if the seal has been damaged or broken.